



## Handy User Information

### SEAFLO WATER PUMPS

#### QUESTION:

My Pump continues to pulsate after the water tap is turned off.

#### RESPONSE:

This could either be:

- **An Air lock** - run all the taps to flush the lines of any air
- **A Small leak on a line**—Check all John Guest fittings are secure and there are no small leaks which are reducing the pressure.
- **Pump Pressure needs to be adjusted**—see below



There is an Hex Head or Allen key screw in the centre of the Pressure Switch (this is the black section to the left of centre on the front of the pump)

- Turning anti-clockwise half a turn will decrease pressure – increases flow (not recommended)
- Turning clockwise in small increments will increase pressure – reduces cycling. It is best to run the pump and taps after each adjustment to check the pressure build up. It is also recommended to bleed any air locks in the lines first.

**STILL UNSURE ? DON'T GUESS– CALL 1800 792 422**